

# IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL FURNISHING, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

## READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

**DANGER** — TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS FURNISHING FROM THE ELECTRICAL OUTLET BEFORE CLEANING.

**WARNING** — TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by, or near children or invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.
7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
9. To disconnect, turn switch to the OFF position, then remove plug from outlet.

10. Never operate the furnishing with any air openings blocked. Keep air openings free of lint, hair, and the like.

11. Do not leave this furnishing unattended when it is plugged in.

12. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.

13. Do not use on a soft surface such as a bed, where openings may be blocked.

14. Turn switch to OFF position and allow unit to cool before cleaning or storage.

15. Do not place or store this furnishing where it can fall or be pulled into a tub or sink.

16. If this furnishing falls into water, unplug it immediately. Do not reach into the water.

17. To protect against electrical hazards, do not use while bathing or in the shower.

18. Never use while sleeping.

19. Do not use bulb greater than 20 watts.

20. Use in any 120 volt, 60 hertz AC electrical outlet (ordinary house current). Do not use it in any other electrical outlet.

## FOR HOUSEHOLD USE ONLY

# SAVE THESE INSTRUCTIONS

# OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this mirror has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Never use with an extension cord unless plug can be fully inserted. Do not change the plug in any way.

**CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.**

1. Your lighted makeup mirror will rotate 360° so that you can use either the normal, flat mirror or the 7x magnifying mirror located on the opposite side.
2. Plug into any standard 120 volt wall outlet. To turn on light, simply turn the switch on the line cord to ON setting.
3. After use, always turn the switch to the OFF position and unplug.

4. The beauty and design of this mirror complement any decor. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see "STORAGE" for detailed information.

## TO REPLACE BULB

**CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB. REPLACE BULB ONLY WITH BULB OF SAME WATTAGE RATING.**

Contact a Conair service center at 1-800-3 CONAIR for replacement bulb information (ask for replacement bulb #HP108. Bulbs are \$1.50 each, including shipping and handling.)

1. Remove screws from left and right sides of mirror. (Fig. 1)
2. Carefully lift off the removable housing from the half that is affixed to the stand.
3. Unscrew the old bulb and replace with the new bulb. (Fig. 2)
4. Carefully replace the removable half after locating and aligning the screw holes to the fixed half.
5. Insert screws into screw holes and tighten.




Figure 1




Figure 2

**CAUTION:**  
TO PREVENT ELECTRIC SHOCK, MATCH WIDE  
BLADE OF PLUG TO WIDE SLOT; FULLY INSERT.

**CAUTION:**  
RISK OF FIRE, USE ONLY 20  
WATTS MAXIMUM 120 VOLT,  
TYPE T BULBS.

**DISCONNECT FROM THE  
SUPPLY CIRCUIT BEFORE  
SERVICING OR CLEANING.**

**DO NOT SUBMERSE.**

**MODEL: BE71CT  
RATING: 120V AC 60Hz 20W  
DATE CODE:**

**STORAGE**

Disconnect from electrical outlet. BE SURE DIRECT  
SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF  
MIRROR WHEN LEFT UNATTENDED. Allow to cool to room  
temperature before storing. Place in cool, dry area out of  
reach of children, where mirror will not be damaged.


Handle cord carefully to prolong its life; do not jerk or  
strain at plug connections, or wrap cord around mirror  
for storage. This could cause damage to the cord or a  
short circuit. To store mirror, coil cord loosely.

**MAINTENANCE**

Your lighted mirror is designed for household use and  
is virtually maintenance free. No lubrication is needed.  
If cleaning becomes necessary, disconnect the appliance  
from the power source and wipe exterior with a damp  
cloth. Clean mirror surfaces with a glass cleaner. Do not  
light until you are certain mirror is completely dry.  
If any abnormal condition occurs, unplug the lighted  
mirror, allow it to cool, and return it to an authorized  
service center for repair.

**WARNING:  
IF YOU THINK THE  
POWER IS OFF  
WHEN THE SWITCH  
IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everybody knows that electricity and water are a  
dangerous combination. But did you know that an  
electrical appliance is still electrically alive even if  
the switch is off? If the plug is in, the power is on.  
So when you are not using your appliances, keep  
them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

**LIMITED ONE YEAR WARRANTY**

Conair will repair or replace (at our option) your unit free  
of charge for 12 months from the date of purchase if the  
appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective  
product to the service center listed below, together with  
your purchase receipt and \$3.00 for postage and handling.  
California residents need only provide proof of purchase and  
should call 1-800-366-0937 for shipping instructions. In the  
absence of a purchase receipt, the warranty period shall be  
12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR  
LIABILITIES, INCLUDING BUT NOT LIMITED TO THE  
IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS  
FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN  
DURATION TO THE 12-MONTH DURATION OF THIS  
WRITTEN, LIMITED WARRANTY.** Some states do not allow  
limitations on how long an implied warranty lasts, so the  
above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY  
SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES  
FOR BREACH OF THIS OR ANY OTHER WARRANTY,  
EXPRESS OR IMPLIED, WHATSOEVER.** Some states do  
not allow the exclusion or limitation of special, incidental,  
or consequential damages, so the above limitation may not  
apply to you.

This warranty gives you specific legal rights, and you may  
also have other rights, which vary from state to state.

**Please register this product at:**  
[www.conair.com/registration](http://www.conair.com/registration)

©2013 Conair Corporation  
**Service Center**  
Conair Corporation  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

Model BE71CT

12PM137039

IB-11893



**REFLECT** *romantic*  
7x1x Magnification Mirror



**CONAIR®**

For your safety and continued enjoyment of this product,  
always read the instruction book carefully before using.

Model BE71CT